

■ Connectable indoor unit list

• This outdoor unit can be connected to these indoor units as shown below.

Type		Model name
Ceiling Cassette	4-way air flow	PLFY-P*VBM* PLFY-P*VEM*
		PLFY-EP*VEM* PLFY-P*VCM* PLFY-P*VFM*
	2-way air flow	PLFY-P*VLMD*
	1-way air flow	PMFY-P*VBM*
Ceiling Concealed		PEFY-P*VMR* PEFY-P*VMS(L)*
		PEFY-P*VMA(L)* PEFY-P*VMA*
		PEFY-P*VMH(S)* *1
	Fresh Air Intake	PEFY-P*VMH*
Ceiling Suspended		PCFY-P*VKM*
Wall Mounted		PKFY-P*VBM* PKFY-P*VHM*
		PKFY-P*VKM*
Floor Standing / Floor Mounted Concealed		PFFY-P*VKM* PFFY-P*VLEM*
		PFFY-P*VLRM* PFFY-P*VLRMM*

1 Only PUMY-P200YKM can be connected to PEFY-P*VMHS.

Connect to branch box(PAC-MK•BC)

Type		Model name
Ceiling Cassette	4-way air flow	SLZ-KF*VA* SLZ-M*FA*
		PLA-RP*EA*
	1-way air flow	MLZ-KA*VA* MLZ-KP*VF*
Ceiling Concealed		SEZ-KD*VAQ(L)* SEZ-M*DA(L)*
		PEAD-RP*JA(L)Q* PEAD-M*JA(L)*
Ceiling Suspended		PCA-RP*KAQ* PCA-M*KA*
Floor standing		MFZ-KJ*VE*
Wall Mounted		MSZ-FH*VE* MSZ-GF*VE*
		MSZ-SF*VA* MSZ-SF*VE*
		MSZ-EF*VE* MSZ-AP*VF*
		MSZ-LN*VG* MSZ-AP*VG*

This information is based on COMMISSION REGULATION (EU) 2016/2281.

NOTE: "*" means suffix such as letters or numbers.