

■ Connectable indoor unit list

• This outdoor unit can be connected to these indoor units as shown below.

Type		Model name	
Ceiling Cassette	4-way air flow	PLFY-P*VBM*	PLFY-M*VEM*
		PLFY-P*VCM*	PLFY-P*VFM*
		PLFY-P*VEM*	
	2-way air flow	PLFY-P*VLMD*	PLFY-P*VMMD*
	1-way air flow	PMFY-P*VBM*	
Ceiling Concealed		PEFY-P*VMR*	PEFY-P*VMS(L)*
		PEFY-P*VMA(L)*	PEFY-P*VMA*
		PEFY-P*VMHS*	PEFY-M*VMA(L)*
		Fresh Air Intake	PEFY-P*VMHS*-F
Ceiling Suspended		PCFY-P*VKM*	
Wall Mounted		PKFY-P*VBM*	PKFY-P*VHM*
		PKFY-P*VKM*	PKFY-P*VLM*
Floor Standing / Floor Mounted Concealed		PFFY-P*VKM*	PFFY-P*VLEM*
		PFFY-P*VLRM*	PFFY-P*VLRMM*
		PFFY-P*VCM*	

Connect to branch box(PAC-MK•BC)

Type		Model name	
Ceiling Cassette	4-way air flow	SLZ-KF*VA*	SLZ-M*FA*
		PLA-RP*EA*	PLA-M*EA*
	1-way air flow	MLZ-KA*VA*	MLZ-KY*VG*
		MLZ-KP*VF*	
Ceiling Concealed		SEZ-KD*VA(L)*	SEZ-M*DA(L)*
		PEAD-RP*JA(L)Q*	PEAD-M*JA(L)*
Ceiling Suspended		PCA-RP*KAQ*	PCA-M*KA*
Floor standing		MFZ-KJ*VE*	MFZ-KT*VG*
Wall Mounted		MSZ-FH*VE*	MSZ-GF*VE*
		MSZ-SF*VA*	MSZ-SF*VE*
		MSZ-EF*VE*	MSZ-AP*VF*
		MSZ-LN*VG*	MSZ-AP*VG(K)*
		MSZ-EF*VG(K)*	MSZ-AY*VGK(P)*

This information is based on COMMISSION REGULATION (EU) 2016/2281.

NOTE: "*" means suffix such as letters or numbers.